



TT1SPSAT Install Addendum - Input Cable Type 2 Installation

IMPORTANT – Please read BEFORE INSTALLATION

Please first consult the TT1SPSAT quick install guidelines for device placement and general operation.

Step 1: Install input cable into Asset

Step 2: Plug input cable into TT1SPSAT

Step 3: After 5 minutes, cut the “Soft Power Down” (Green/Yellow) connection

Yellow	Soft Power Down (Normally Open)
Green	Ground
White	Dry Contact 1 (Recommended for Ignition Input)
Black	Ground
Light Blue	Dry Contact 2
Pink	Ground
<i>IMPORTANT: Designed to work with 3.3V logic only, Do not use 5V logic devices Be certain that unused wires DO NOT short to each other</i>	

Please do not hesitate to contact CTS at (780) 391-3800 should you have any questions.