



STEP 1 POSITION THE IRIDIUM MODULE IN AN OPTIMAL LOCATION

- Secure in upper portion of the dash in a hidden location with Iridium logo towards the sky. (Example: Above Instrument Cluster)
- Do NOT cover with metal or position near any source of interference (Vehicle Radio, BCM). Keep a safe distance of at least 24".

Failure to adhere to these suggestions will result in a weak Iridium signal and will affect the performance of the device.

STEP 2 COMPLETE THE WIRING CONNECTIONS

- Ensure connections are completed on the main 24 pin wiring harness according to the TT6000 Quick Install Guide
- Route the CBL0041 Iridium connector harness from the Iridium modem to the 24 pin harness location
- Connect both the 6 pin and 8 pin connectors of the CBL0041 harness to the TT6000 24 pin harness

STEP 3 CALL TO TEST

IMPORTANT: MUST BE TESTED | FAILURE TO FOLLOW INSTRUCTIONS MAY VOID WARRANTY

1.780.391.3800 | TOLL FREE: 1.855.287.4477

8:00 AM to 5:00 PM MON-FRI MST

